

Directional control valves hydraulically operated type WHG6/WHP6

WK 425 710

NS₆

up to 35 MPa

up to 80 dm³/min

09.2016

DATA SHEET - OPERATION MANUAL

APPLICATION

Directional control valves hydraulically operated type **WHG6...**, **WHP6...** are intended for change in direction of fluid flow in a hydraulic system and thus it allows to change direction of movement of a receiver - mostly piston rod of a cylinder or hydraulic motor as well to use functions: *on* and *off*. There are available versions with various methods of pilot oil connection:

- •hydraulically operated type **WHG6**... threaded connection of pilot oil
- •hydraulically operated type **WHP6**... subplate connection of pilot oil


These directional spool valves are used for subplate mounting in any position in a hydraulic system.



DESCRIPTION OF OPERATION


Directional control valve hydraulically operated with threaded pilot oil connection type WHG6...

The spool (2) is shifted after pilot fluid is supplied to the caps connection (3). Return of spool (2) and its centring in zero position (3-position directional control valves) or setting of end positions (2-position directional control valves) follows by means of the springs (4) and centring plates (5) - version WHG6.../•••, hydraulically (oil pressure) - version WHG6.../O... or by means of detent - version WHG6.../OF.... In version WHG6.../O... spool position (2) is not set in case of the lack of control pressure. The valve can be equipped with throttle insert (6) mounted in **P** port version WHG6.../...**B**.



Directional control valve hydraulically operated with subplate pilot oil connection type WHP6...

The spool (2) is shifted after pilot fluid is supplied to the chambers of caps (3) through ports **X** and **Y** from subplate connection. Return of spool (2) and its centring in zero position (3-position directional control valves) or setting of end positions (2-position directional control valves) follows by means of the springs (4) and centring plates (5) - version WHP.../•••, hydraulically (oil pressure) - version WHP6.../**O**... or by means of detent - version WHP6.../OF.... In version WHP6.../O... spool position (2) is not set in case of the lack of control pressure. The valve can be equipped with throttle insert (6) mounted in **P** port - version WHP6.../...**B**.



TECHNICAL DATA

Hydraulic fluid	mineral oil				
Required fluid cleanliness class	ISO 4406 class 20/18/15				
Nominal fluid viscosity	37 mm ² /s at temperature 55 °C				
Viscosity range	$2.8 \text{ up to } 380 \text{ mm}^{2}/\text{s}$				
Fluid temperature range (in a tank)	recommended	40 °C up to 55 °C			
	max	-20°C up to +70°C			
Ambient temperature range	- 20°C up to +70°C				
Directional valve parameters	type WHG6		type WHP6		
Maximum operating pressure	ports P, A, B	35 MPa	ports P, A, B	35 MPa	
	port T	21 MPa	port T	21 MPa	
Control pressure	min. 2,0 MPa		min. 2,0 MPa		
	max. 20 MPa		max. 20 MPa		
Weight	1,1 kg		1,0 kg		

INSTALLATION AND OPERATION REQUIREMENTS

- Only fully functional and operational directional valve can be used.
- 2. During the operation one must maintain the recommended fluid viscosity acc. to requirements defined in this Data Sheet Operation Manual.
- 3. In order to provide failure-free and safe operation of the directional valve, one should systematically check:
 - proper working of the valve
 - cleanliness of the hydraulic fluid
- Due to heating of the directional valve body to high temperature, the directional valve should be placed in such a way to eliminate the risk of
- accidental contact with the directional valve body during operation or one should provide suitable covers compliant with the requirements of European standards: PN EN ISO 13732 1 and PN EN 4413.
- 5. In order to provide tightness of the valve connection to the hydraulic system, one should keep the dimensions of the sealing rings, tightening torques and directional valve operation parameters specified in this Data Sheet Operation Manual.
- A person operating the valve must be thoroughly familiar with the content of this Data Sheet -Operation Manual.


DIAGRAMS

Graphic symbols of 3-position Graphic symbols of 2-position directional control valves directional control valves versions with positions a, 0 versions with positions 0, b Graphic symbols of spools working and working working working and working and working indirect positions positions positions indirect positions indirect positions positions а EB HB


DIAGRAMS

Graphic symbols of 2-position directional control valves


versions with positions a, b





Graphic symbols of spools




OVERALL AND CONNECTION DIMENSIONS type WHG6...













- 1 Cover with control port a
- 2 Cover with control port \boldsymbol{b}
- 3 Sealing ring o-ring 9,2 x 1,8 pcs 4/set
- 4 Porting pattern of the subplate surface compliant with ISO 4401 standard designation ISO 4401-03-02-0-94 (CETOP 03); fixing screws M5 x 50 -10.9 acc. to PN EN ISO 4762 pcs 4/set; tightening torque Md = 9 Nm
- 5 Subplate surface required

OVERALL AND CONNECTION DIMENSIONS type WHP6...










- 1 Cover with chamber of control connection **X** (side **a**)
- 2 Cover with chamber of control connection **Y** (side **b**)
- 3 Sealing ring **o-ring 9,2 x 1,8** pcs 4/set
- 4 Sealing ring **o-ring 4,87 x 1,8** pcs 2/set
- 5 Porting pattern of the subplate surface compliant with ISO 4401 standard designation ISO 4401-03-02-0-94 (CETOP 03); fixing screws M5 x 50 -10.9 acc. to PN EN ISO 4762 pcs 4/set; tightening torque Md = 9 Nm
- 6 Subplate surface required

PERFORMANCE CURVES

measured at viscosity $v = 41 \text{ mm}^2/\text{s}$ and temperature $t = 50^{\circ}\text{C}$

Flow resistance curves


characteristic curves $\Delta \mathbf{p}$ (**Q**) for directional valves type **WHG6**..., **WHP6**... in versions with various spool types




spool symbol	performance diagram number					
shifted positions diagrams according	flow direction					
to pages 2, 3	$P \rightarrow A$	$P \rightarrow B$	$A \!\to\! T$	$B \rightarrow T$		
A, B	3	3	-	-		
D, Y	5	5	3	3		
E	3	3	1	1		
G	7	7	6	6		
Н	2	4	2	2		
J	1	1	2	1		
M	2	4	3	3		
central position	flow direction					
diagram according to page 2	$P \rightarrow A$ $P \rightarrow B$	$P \rightarrow T$	$\begin{array}{c} A \rightarrow T \\ B \rightarrow T \end{array}$	$B \rightarrow A$		
G	-	8	-	-		

Operating limits

characteristic curves **p - Q** for directional valves type **WHG6**..., **WHP6**... in versions with various spool types






performance **spool symbol -** diagrams according to pages 2, 3 diagram number Ε D/OF 2 D/0 3 D, Y 4 A. B 5 6 G 7 M 8 9 Н

NOTE:

Above operating limits are reached by minimal operating pressure $\mathbf{p} = \mathbf{2MPa}$ and symmetrical flow through all ports i.e. if the oil flows from port \mathbf{P} to port \mathbf{A} , then the same oil amount flows from port \mathbf{B} to port \mathbf{T} . Degree of asymmetry has negative impact on the parameters.



NOTES:

The directional valves should be ordered according to the above coding.

The symbols in bold are the preferred versions in short delivery time.

Coding example: 4WHG6 E - 42

SUBPLATES AND FIXING SCREWS

Subplates must be ordered according to catalogue sheet **WK 496 480**. Subplate symbols:

G 341/01 - threaded connections G 1/4

G 342/01 - threaded connections G 3/8

G 502/01 - threaded connections G 1/2


G 341/02 - threaded connections M14 x 1,5

G 342/02 - threaded connections M16 x 1,5

<u>The subplate symbol in bold is the preferred</u> version available in short delivery time.

Subplates and fixing screws M5 x 50 - 10,9 according to PN - EN ISO 4762 - pcs 4/set must be ordered separately. Tightening torque Md = 9 Nm

EXAMPLE OF APPLICATION IN A HYDRAULIC SYSTEM



PONAR Wadowice S.A. ul. Wojska Polskiego 29 34-100 Wadowice tel. +48 33 488 21 00 fax.+48 33 488 21 03

www.ponar-wadowice.pl

